HP One-Button Disaster Recovery (OBDR)

For Current Shipping ProLiant Servers

Tape Drive / ISV Compatibility Matrix **March 2015**

IMPORTANT: ODBR is not supported after Windows 2012 / RHEL 6.x or SLES 11.1.

IMPORTANT: ODBR is not supported after HP Proliant Gen8 servers.

Tape Device	Microsoft			Microsoft			Linux (x86 and x64)			
	Windows Server 2012			Windows Server 2008 (x86 and x64) SP2, R2			RHEL 5.x RHEL 6.x		SLES 10.x SLES 11.1	
	Yosemite Server Backup 10.1	HP Data Protector Express 6.0	HP Data Protector 8.0	Yosemite Server Backup 10.1[1]	HP Data Protector Express 6.0	HP Data Protector 8.0	Yosemite Server Backup 10.1[2]	HP Data Protector Express 6.0	Yosemite Server Backup 10.1	HP Data Protector Express 6.0
HP DAT 72 SCSI			√	√	√	√	√	√	√	√
HP DAT 72 USB			√	√	√		√	√	√	√
HP DAT 160 SCSI			√	√	√	√	√	√	√	√
HP DAT 160 SAS			√	√	√	√	√	√	√	√
HP DAT 160 USB			√	√	√		√	√	√	√
HP Ultrium 448 SCSI			√	√	√	√	√	√	√	√
HP Ultrium 920 SASI			√	√	√	√	√	√	√	√
HP Ultrium 920 SCSI			√	√	√	√	√	√	√	√
HP Ultrium 1760 SCSI			√	√	√	√	√	√	√	√
HP Ultrium 1760 SAS			√	√	√	√	√	√	√	√
HP Ultrium 1760c Tape Blade			√	√	√	√	√	√	√	√
HP Ultrium 1840 SCSI			√	√	√	√	√	√	√	√
HP Ultrium 1840 SAS			√	√	√	√	√	√	√	√
HP Ultrium 3280 SAS			√	√	√	√	√	√	√	√
HP Ultrium 3000 SAS			√	√	√	√	√	√	√	√
HP Ultrium 3000c Tape Blade			√	√	√	√	√	√	√	√
HP Ultrium 6650 SAS			√	√		√	√		√	
HP Ultrium 6250 SAS			√	√		√	√		√	

Notes:

1. **When restoring using a Smart Array Controller, the new hard drive must be a larger capacity than the failed hard drive**
2. **OBDR is not supported with SCSI tape drives in a server running RHEL 6.3**

HP One-Button Disaster Recovery (OBDR)

For Current Shipping ProLiant Servers

ProLiant Server / Controller Compatibility Matrix **March 2015**

IMPORTANT: ODBR is not supported after Windows 2012 / RHEL 6.x or SLES 11.1.

IMPORTANT: ODBR is not supported after HP Proliant Gen8 servers.

OBDR is supported with an HP Tape Drive attached to the following HP ProLiant Servers and Controllers:

A: SC11Xe SCSI Host Bus Adapter	412911-B21
B: Smart Array P212/ZM, Smart Array P212/256MB	462828-B21, 462834-B21
C: Smart Array P410/256MB, Smart Array P410/512MB with BBWC	462862-B21, 462864-B21
D: Smart Array P411/256MB, Smart Array P411/512MB with BBWC	462830-B21, 462832-B21
E: Smart Array P812	487204-B21
F: Smart Array P222	631667-B21
G: Smart Array P420/1GB, Smart Array, P420/2GB	631670-B21, 631671-B21
H: Smart Array P421/1GB, Smart Array, P421/2GB	631673-B21, 631674-B21
I: Smart Array P822	615418-B21
J: H220 Host Bus Adapter	650933-B21
K: H221 Host Bus Adapter	650931-B21
L: H222 Host Bus Adapter	650926-B21

HP ProLiant Server - DL Series	Attach tape device to this Controller
Microserver Gen8	F
Microserver	B
DL160 Gen8	A, F, H, I, K L
DL320e Gen8 v2	A, F, H, I, K L
DL320e Gen8	A, F, H, I, K L
DL360e Gen8	A, F, H, I, K L
DL360p Gen8	A, F, H, I, K L
DL380e Gen8	A, F, H, I, K L
DL380p Gen8	A, F, H, I, K L
DL385p Gen8	A, F, H, I, K L
DL560 G8	A,B,D,E
DL580 G8	A,B,D,E
DL585 G7	A,B,D,E
DL980 G7	A,B,D,E

HP ProLiant Server - ML Series	Attach tape device to this Controller
ML310e Gen8 v2	A, F,G,H,I J K,L
ML310e Gen8	A, F,G,H,I J K,L
ML350e Gen8 v2	A, F,G,H,I J K,L
ML350p Gen8	A, F,G,H,I J K,L

Notes:

Make sure your ProLiant server has the most recent BIOS - System ROM installed

Make sure your HP storage controller has the most recent firmware installed